



4962X BIG BORE SHOCK INSTALLATION



Remove the upper shock cap. Fill the shock with oil until it is about 3/4 full. SLOWLY move the piston up and down, while twisting it in the cylinder (always keeping it submerged in oil) to release the air bubbles. Be careful not to squirt oil in your face by moving the piston too rapidly. Finish filling the shock until the oil level is 1.5mm from the top edge of the shock body. Allow any remaining air bubbles to surface, then screw on the upper shock cap. Tighten the upper cap only finger tight. Over-tightening may damage the rubber diaphragm and cause leakage. Exercise the shock. It should operate smoothly and quietly. If it squeaks, remove all trapped air bubbles in the shock body by removing the upper cap and allowing the bubbles to surface and break.

- CCS.....Countersunk Caphead Screw
- CSCaphead Machine Screw
- CM.....Countersunk Machine Screw
- RM.....Roundhead Machine Screw
- NL.....Nylon Locknut
- EE-clip



For customer assistance, call toll-free
1-888-TRAXXAS.
E-mail: support@traxxas.com.

