

- 1) You may place the Roof Skid Rails anywhere you'd like on the roof of your X-Maxx, running front-to-back (do not install side-to-side). Our preference is to the outside of the strengthening ribs on the roof. Once you decide where you'd like the Roof Skid Rails, tip them on their side and place the Support Plates in their place, aligning the holes in the Support Plate with those in the Roof Skid Rails. The Support Plate will be used as a drilling guide.
- 2) Mark the 6 screw hole locations (3 per side) on the body, remove the Support Plate, then drill those hole locations using a 1/8" (3mm) drill.
- 3) Move the Support Plates under the body and, using all of the included M3 x 10mm screws, bolt the Roof Skid Rails to the roof, using the Support Plates as a buffer between the screw heads and the body of the truck.