#80632 - Body Savers for the Traxxas Rustler 4x4

What's Included: 2 - Front Body Savers, 2 - Rear Body Savers & 8 - M3 x 14mm buttonhead screws

Before Your Begin: Remove the eight screws (four front and four rear) holding the body mounts (Traxxas #6719) to the body. You may discard the stock screws. If you leave the screws Front Body

holding the body support (Traxxas #6718) in place, the front and rear body mounts will stay in place.

Front Body Savers: Review the illustrations to the right. The Front Body Savers are directional. Make sure the larger boss at the rear of the Body Savers drops into the hole location closest to the windscreen of your truck. For visual reference, the louvers should face towards the rear of the vehicle and the angled slope should ramp up and to the outside of the vehicle. Bolt in place using the included M3 x 14mm buttonhead screws.

Rear Body Savers: Review the illustration to the right. The Rear Body Savers are directional as well. Make sure the Rear Body Savers follow the contours of the rear of your truck. When properly placed, they'll fall right into their correct location. Bolt in place using the included M3 x 14mm buttonhead screws

Saver Orient Towards Windscreen Front of Vehicle Front Body Saver Upward Slope Towards Outside Edge of Body Rear Body Saver

Front of Vehicle