


VUSION

HOUSERACER

The battery connector is designed to fit tight so it will not come apart during the normal bumps and jolts of FPV flying.



1. To connect, firmly push the two connectors together and then make sure the battery is fully inserted into the holder.
2. To disconnect, remove the battery from the holder, grasp both connectors and pull firmly. **Note:** The connector interlocks. Be careful not to accidentally grip both parts with your left hand. Do not pull on the wires.