

HUDY®

HUDY PERSONAL RACING DISPLAY

#107850

FEATURES

- Compact all-in-one data center for RC car drivers
- Indicators for:
 - > **time** > **temperature** > **humidity** > **date** > **alarm**
- Environment comfort display:
 - > **comfortable** > **wet** > **dry**
- Temperature range: **0–50°C (32–120°F)**
- Temperature shown in **°C and °F**
- Max & Min temperature and humidity memory
- Time indicator in **12hr or 24hr clock**
- Extra features: > **date** > **alarm clock**
- Temperature accuracy: **± 1.0°C (±1.8°F)**
- Temperature resolution: **0.1°C (0.1°F)**
- Humidity measuring range: **10–90% RH**
- Humidity accuracy: **±5% (40–80%) other ±8%**
- Power: **AAA 1.5V battery (included)**

BASIC FUNCTIONS

MODE: clock/alarm switch, setting clock & alarm & calendar

ADJ: adjust the value of item, alarm on/off, date indication

MEMO: indicates MAX/MIN temperature and humidity
°C / °F: °C / °F temperature switch

RESET: clears all settings & memory back to their original states (at rear)

°C / °F: Switches between °C and °F (at rear)




TIME AND DATE SETTING

- Press and hold **[MODE]** for 3 seconds until the minute starts flashing; press **[ADJ]** to adjust the minutes.
- Press **[MODE]** again until the hour flashes; press **[ADJ]** to adjust the hour.
- Press **[MODE]** again to set the clock mode; press **[ADJ]** to select 12hr mode (US time) or 24hr mode (EU time)
- Press **[MODE]** again until the month flashes; press **[ADJ]** to adjust the month.
- Press **[MODE]** again until the date flashes; press **[ADJ]** to adjust the date.
- Press **[MODE]** to confirm.

ALARM CLOCK SETTING

- Press **[MODE]** to display the alarm clock time, then press and hold **[MODE]** for 3 seconds until the minute starts flashing; press **[ADJ]** to adjust the minute.
- Press **[MODE]** again until the hour flashes; press **[ADJ]** to adjust the hour.
- Press **[MODE]** twice to confirm.

ALARM CLOCK ON/OFF

- Press **[MODE]** to enter the alarm clock state.
- Press **[ADJ]** and the alarm clock symbol  will appear.
- Press **[ADJ]** and the announce hour symbol  will appear.
- When the announce hour symbol is switched on the HUDY Personal Racing Display will announce the hour by a double beep.
- Press **[ADJ]** once again, and the alarm clock and announce hour symbols will appear together (meaning that the alarm clock and announce hour function are both turned on simultaneously). 
- Press **[MODE]** to confirm ON.
- Continue to press **[ADJ]** to toggle the alarm clock off.
- Press **[MODE]** to confirm OFF.

CALENDAR DISPLAY

- With the clock mode active, press **[ADJ]** to display the date. It will automatically revert back after 3 seconds.

MAX/MIN HUMIDITY AND TEMPERATURE DISPLAY

- Press **[MEMO]** to display MAX/MIN humidity and temperature from memory.
- Press and hold **[MEMO]** for 2 seconds to clear the memory.

ENVIRONMENT COMFORT DISPLAY

- The **[COMFORT]** indicator appears when the temperature is 20-26°C (68-78.8°F) and relative humidity is 50-70% RH.
- The **[WET]** indicator appears at any temperature when relative humidity is higher than 70% RH.
- The **[DRY]** indicator appears at any temperature when relative humidity is below 50% RH.

BATTERY

- The display unit uses a AAA 1.5v dry cell battery. When the battery is drained, dispose of properly.

info@hudy.net

www.hudy.net

HUDY, PRED POLOM 762, 911 01 TRENCIN, SLOVAKIA, EUROPE