



## Jato® (Model 55077-3) Parts List

Parts shown in bold are optional accessories. Part categories and individual part listings are arranged alphabetically.

### Air Filters

5265	Air filter housing/ foam insert/ Jato® air filter base (long, straight)/ cable tie (1-each) (TRX® 2.5)
5261	Air filter inserts, foam (3) (pre-oiled) (TRX® 2.5)
5263	Air filter oil

### Bearings & Bushings

4609	Ball bearings (5x10x4mm) (2) (metal shielded, for clutch bell)
4611	Ball bearings (5x11x4mm) (2) (metal shielded, for clutch bell)
5119	Ball bearings, blue rubber sealed (10x15x4mm) (2)
5124	Ball bearings, blue rubber sealed (4x7x2.5mm) (2)
5116	Ball bearings, blue rubber sealed (5x11x4mm) (2)
5114	Ball bearings, blue rubber shield (5x8x2.5mm) (2)
5123	Bellcrank bushings (plastic) (4x7x2.5mm) (4)
2545	Bushings (plastic) (5x8x2.5mm) (4)

### Body & Accessories

1926	Antenna caps, vinyl (2)/ antenna spool
5526	Antenna crimp nut, aluminum (blue-anodized)/ antenna nut tool
5526R	Antenna crimp nut, aluminum (red-anodized)/ antenna nut tool
1726	Antenna, tube (1)/ vinyl antenna cap (1)/ wire retainer (1)
3935	Body clip (mounting clip), angled, 90-degrees (10)
3935A	Body clip (mounting clip), angled, 90-degrees (black) (10)
1834	Body Clips (12) (standard size)
5514	Body mount, front
5511R	Body, Jato® 3.3, ProGraphix® (replacement for the painted body) Graphics are painted, requires paint & final color application.)
5511T	Body, Jato®, orange (painted, decals applied)
5511A	Body, Jato®, red (painted, decals applied)
5513X	Decal sheet, Jato® 3.3
2514	Decal sheet, racing sponsors
9950	Official Team Traxxas® racing decal set(flag logo/ 6-color)
5512	Wing mounting hardware, (4x8mmCCS (aluminum)(3)/ 4x7mm flanged NL (3)

### Brake Components

5588	Brake cam
5567	Brake cam lever/ linkage rod/ bellcrank/ 4mm Ball Screw (1)/ 4mm Ball Cup (1)/ 3.0NL (1)/ 3X10 SS (1)
5564A	Brake disc (semi-metallic material)
5565	Brake pads (2)/ brake disc hub/ 3X15 CS (partially threaded) (2)/2mm pin (1)/ 4mm e-clip (1)
5566	Input shaft (slipper shaft)/ slipper shaft spacer
5568	Linkage set, throttle & brake (Jato®) (includes servo horn, rod guides, brake spring, brake adjustment dial, rods (wires), throttle return spring, hardware)

### Bumpers & Skidplates

5515X	Battery Box, bumper (rear) (includes battery case with bosses for wheelie bar, cover, and foam pad)
5535	Bumper, front
5520	Bumper, rear (for use with mid-mounted RX battery)
5185	Tires, rubber (2) (fits Traxxas® wheelie bar wheels)
5584	Wheelie bar/ rear skid (assembled) (fits Jato®, requires 5515X for installation)
4976	Wheels (4)/ Axles (2), for wheelie bar
5186A	Wheels, aluminum (blue-anodized) (2)/ 5x8mm ball bearings (4)/ axles (2)/ rubber tires (2)
5186	Wheels, aluminum (red-anodized) (2)/ 5x8mm ball bearings (4)/ axles (2)/ rubber tires (2)
9461X	Wheels, wheelie bar, 6061-T6 aluminum (blue-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461G	Wheels, wheelie bar, 6061-T6 aluminum (green-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461A	Wheels, wheelie bar, 6061-T6 aluminum (orange-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461P	Wheels, wheelie bar, 6061-T6 aluminum (pink-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461R	Wheels, wheelie bar, 6061-T6 aluminum (red-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)

### Chassis & Attachments

5515X	Battery Box, bumper (rear) (includes battery case with bosses for wheelie bar, cover, and foam pad)
3039	Battery holder, 4-cell (no on/off switch) (for Jato® and others that use a male Futaba style connector)
5530	Bulkheads, front (upper & lower)

5520	Bumper, rear (for use with mid-mounted RX battery)
5523	Chassis top plate
5522	Chassis, 6061-T6 aluminum (3mm) (blue anodized)/ adhesive foam pad (1)
5522X	Chassis, 7075-T6 aluminum (3mm) (Titanium-anodized) (machined, lighter than stock)/ adhesive foam pad (1)
5592	Clutch guard
5527	Dirt guards, chassis (left & right)
5560	Engine mount/ engine mount spacers (2)/ 3x15 CS with washers (4)/ 4x18 BCS (2)/ flathead engine mount screws 3x10 (2)
5581	Gaskets, differential/transmission
5559	Mounts, suspension pin (rear anti-squat blocks) (1.5, 2.25, 3.0 & 3.75 degree) (1 each)
5524	Receiver box cover (for chassis top plate)/ battery cover (mid chassis)
5516	Roll Hoop (composite)/ EZ-Start® plug mount
5583	Rubber plugs, charge jack, 2-speed adjustment (Jato®)
5519	Servo mounts, steering (left & right)
9461X	Wheels, wheelie bar, 6061-T6 aluminum (blue-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461G	Wheels, wheelie bar, 6061-T6 aluminum (green-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461A	Wheels, wheelie bar, 6061-T6 aluminum (orange-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461P	Wheels, wheelie bar, 6061-T6 aluminum (pink-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
9461R	Wheels, wheelie bar, 6061-T6 aluminum (red-anodized) (2)/ 5x8x2.5mm ball bearings (4)/ o-rings (2)/ 5x8x0.3mm TW (2)
3038	Wiring harness, on-board radio system (includes on/off switch and charge jack)

### Clutch & Related Parts

4609	Ball bearings (5x10x4mm) (2) (metal shielded, for clutch bell)
4611	Ball bearings (5x11x4mm) (2)
4118	Clutch bell (18-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x10x4mm ball bearings part 4609)
4120	Clutch bell (20-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x11x4mm ball bearings part 4611)
4122	Clutch bell (22-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x11x4mm ball bearings part 4611)
4124	Clutch bell, (24 tooth) / 5x8x0.5mm fiber washer (2)/ 5mm E-clip (requires #4611-ball bearings, 5x11x4mm (2))
4146X	Clutch shoes (2)/ spring
3281	Cone, split beveled
1633	E-clips/ C-rings
6542X	Flywheel (large, knurled for use with starter boxes)
5244	Flywheel nut (TRX® 2.5 and 2.5R)
6542	Flywheel with magnet (35mm)
1985	PTFE-coated Washers, 5x8x0.5mm (20) (use with ball bearings)

### Differential Components

5119	Ball bearings, blue rubber sealed (10x15x4mm) (2)
5580	Cover, differential
5136X	Differential oil kit (1 each: 10K, 30K, 50K weights)
5581	Gaskets, differential/transmission
5582	Gear set, differential (output gears (2)/ spider gears (2)/ spider gear shaft)
5579	Gears, differential 38-T (1)/ differential drive gear 20-T/ side cover plate (1)/ gasket (1)/ output gear seals (x-ring) (2)/ 2.5x8mmCCS (4)/ 5x10x.5mmTW (2)
5130	Oil, differential (100K wt) (0.7 oz (20cc))
5135	Oil, differential (10K wt) (1.7 oz (50cc))
5039	Oil, differential (500K wt) (0.7 oz (20cc))
5137	Oil, differential (50K wt) (1.7 oz (50cc))
2524	Screws, 2.5x8 countersunk machine (hex drive) (6)
2577	Screws, 3x10mm button-head machine (hex drive) (6)

### Driveline Components

5555	Carriers, stub axle (rear) (left & right)
5555X	Carriers, stub axle, (rear) 6061-T6 aluminum (titanium-anodized)
5528	Differential output yokes (2)/yoke pins M3/12.5 (2)
5551	Driveshaft assembly (1), left or right (fully assembled, ready to install)/ M3/12.5mm yoke pin (1)
5551X	Driveshafts, Jato® (steel constant-velocity) (lubed with inner and outer dust boots) (1 pair)
5150	E-clips, 1.5mm (24)
5550	Half shaft set, left or right (internal splined half shaft/ external splined half shaft/ rubber boot/ metal U-joints) (assembled with glued boot) (2 assemblies)

2754	Stub axle pins (4)
5553	Stub axles, (rear) (2)
1654	Wheel hubs, hex (2)/ stub axle pins (2)

### Engine & Servo Mounts

4859	CS 3x10 flathead (hex drive)
5560	Engine mount/ engine mount spacers (2)/ 3x15 CS with washers (4)/ 4x18 BCS (2)/ flathead engine mount screws 3x10 (2)
2547	Screws, 4x18mm countersunk machine (hex drive) (6)
5519	Servo mounts, steering (left & right)

### Engine Components

5238R	Cooling head, PowerTune (machined aluminum, blue- anodized) (TRX® 3.3), head protector (1), 3x6mm CCS (5)
5270R	EZ-Start® 2, complete system with controller, drive unit, wiring harness
3980	Glow plug wrench (Universal wrench)
3232X	Glow plug, super-duty (long-medium)/gasket
5228	Head protector, cooling head (1)/3x6mm CCS (5) (TRX® 3.3)
5290	Piston/Sleeve (Matched Set), Wrist Pin Clips(2) (TRX® 3.3)
5211R	Roller clutch/ 6x8x0.5 TW (1) (also called one-way bearing) (TRX® 2.5, 2.5R, 3.3)
5277	Shaft, starter (TRX® 2.5 & 2.5R)
5170	<b>Starter, recoil (complete with screws) (TRX® 2.5)</b>

### Exhaust

5546	Hanger, metal (for tuned pipe)/ 4x8 BCS (1)/ 3x10 BCS (1)
5540	Header, exhaust (Jato®) (tubular aluminum, clear anodized) (TRX® 2.5, 2.5R)
5256	O-ring, header 12.2x1mm (TRX® 2.5)
5245X	<b>Pipe coupler, molded (black)/ exhaust deflector (rubber, black)/ cable ties, long (2)/ cable ties, short (2)</b>
5245	Pipe coupler, molded (blue)/ Exhaust deflector (rubber, blue)/ cable ties, long (2)/ cable ties, short (2)
5142	Screws, 3x15mm caphead machine (hex drive) (with split and flat washers) (6)
5485	<b>Tuned pipe, Resonator®, R.O.A.R. legal (dual-chamber, enhances mid to high-rpm power) (for Jato®, N. Rustler®, N. 4-Tec® with TRX® Racing Engines)</b>
5483	<b>Tuned pipe, Resonator®, R.O.A.R. legal (single-chamber, enhances low to mid-rpm power) (for Jato®, N. Rustler®, N. 4-Tec® with TRX® Racing Engines)</b>
5541X	Tuned pipe, Resonator®, R.O.A.R. legal, blue-anodized (aluminum, single chamber) (fits Jato®, N. Rustler®, N. 4-Tec®, with TRX® Racing Engines)

### EZ Start 2 & Related parts

5280	Control box (complete) (EZ-Start® 2)
5281	Control box battery cover w/ belt clip (EZ Start 2)
5273	Cush-drive elements (4) (EZ Start 2)
4583	EZ Start 2 wiring harness (for Jato®)
5270R	EZ-Start® 2, complete system with controller, drive unit, wiring harness
5276	Gear set (complete) (EZ-Start® 2)
5148	<b>Grease, white lithium</b>
5275	Housing set (inner, outer)/ 3x12mmBCS (5)/ 3x20BCS (1)/ motor bushing (EZ-Start® 2)
4581X	Lead wire, glow plug (blue) (EZ-Start® and EZ-Start® 2)/ molex pin extractor (use where glow plug wire does not have bullet connector)
5279	Motor (hi-torque)/ pinion gear/ motor bushing (EZ-Start® 2)
5211R	Roller clutch/ 6x8x0.5 TW (1) (also called one-way bearing) (TRX® 2.5, 2.5R, 3.3)
5169	Screws, 2.6x8mm countersunk machine (6) (EZ Start 2 motor)
5282	Screws, 3x12mm button-head machine (6) (Starter attachment screws w/ threadlock)
2578	Screws, 3x12mm button-head machine (hex drive) (6)
5277	Shaft, starter (TRX® 2.5 & 2.5R)

### Front Suspension

5530	Bulkheads, front (upper & lower)
5536	<b>Caster blocks, 25-degree (left &amp; right)/ steering blocks, 25-degree (left &amp; right)</b>
5532	Caster blocks, 30-degree (left & right)/ steering blocks, 30-degree (left & right)
5525	Rod ends (12)/ hollow balls (12)
5525R	<b>Rod ends, heavy duty (Jato®/Slayer) (8)</b>
5529	Shim set (for adjusting Jato roll center)/ hollow balls (for inner camber links) (4)
5518	Shock tower, front
5531	Suspension arms, front (left & right)
5521	Suspension pin set, complete (hardened steel, front & rear), 3x27mm (4) 3x35(2), 3x52mm (4)
5589X	Sway bar kit (front and rear) (includes sway bars and linkage)
5596	Sway bars (front) (includes Soft, Medium, Hard)

5558	Tie bars (front & rear)
5537	Wheel spindles, front (left & right) (2)
5537X	<b>Wheel spindles, front, 7075-T6 aluminum, blue-anodized (left &amp; right)</b>

### Fuel Tank & Line

3935	Body clip (mounting clip), angled, 90-degrees (10)
3935A	<b>Body clip (mounting clip), angled, 90-degrees (black) (10)</b>
3147X	Fuel line (610mm or 2ft)
5548	Fuel tank (75cc, complete)
3149A	Heat shield tubing, fiberglass (2) (black)
5547	Pull ring (1)/ fuel tank cap (1)/ engine shut-off clamp (1)/ 3x10 BCS (1)
5549	Rebuild kit, fuel tank (includes: o-ring, grommets (2), cap spring, hardware)

### Fuel, Lubricants & Supplies

5263	<b>Air filter oil</b>
5001	Bottle, Fuel filler (500cc)
3232X	Glow plug, super-duty (long-medium)/gasket
5148	<b>Grease, white lithium</b>
5130	<b>Oil, differential (100K wt) (0.7 oz (20cc))</b>
5135	Oil, differential (10K wt) (1.7 oz (50cc))
5136	<b>Oil, differential (30K wt) (1.7 oz (50cc))</b>
5039	<b>Oil, differential (500K wt) (0.7 oz (20cc))</b>
5137	<b>Oil, differential (50K wt) (1.7 oz (50cc))</b>
5001R	Rebuild kit, fuel filler bottle (includes bottle lid (1) and dispensing tube caps, rubber (2) (fits 8mm or 5/16" dispensing tube))
5070	<b>Top Fuel®, 20% Nitro (gallon)</b>
5020	<b>Top Fuel®, 20% Nitro (quart)</b>
5080	<b>Top Fuel®, 33% nitro (gallon)</b>
5030	<b>Top Fuel®, 33% nitro (quart)</b>

### Hardware

5526	Antenna crimp nut, aluminum (blue-anodized)/ antenna nut tool
5526R	<b>Antenna crimp nut, aluminum (red-anodized)/ antenna nut tool</b>
3935	Body clip (mounting clip), angled, 90-degrees (10)
3935A	<b>Body clip (mounting clip), angled, 90-degrees (black) (10)</b>
1834	Body Clips (12) (standard size)
4859	CS 3x10 flathead (hex drive)
5150	E-clips, 1.5mm (24)
1633	E-clips/ C-rings
5477	Flat wrench, 5mm (blue anodized aluminum)
5478	Flat wrench, 8mm (blue anodized aluminum)
3980	Glow plug wrench (Universal wrench)
5476X	Hex wrenches; 1.5mm, 2mm, 2.5mm, 3mm, 2.5 ball
5475	Multi-tool (plastic)
5158	Nuts, 2.5mm nylon locking (12)
2745	Nuts, 3mm nylon locking (12)
1747P	<b>Nuts, 4mm flanged nylon locking (aluminum, pink anodized) (4)</b>
3647	<b>Nuts, 4mm flanged nylon locking (steel, serrated) (8)</b>
1747	Nuts, 4mm nylon locking (10)
1747R	<b>Nuts, aluminum, flanged, serrated (4mm) (blue-anodized) (4)</b>
1747G	<b>Nuts, aluminum, flanged, serrated (4mm) (green-anodized) (4)</b>
1747T	<b>Nuts, aluminum, flanged, serrated (4mm) (orange-anodized) (4)</b>
1747A	<b>Nuts, aluminum, flanged, serrated (4mm) (red-anodized) (4)</b>
3229	Screws, 2.5x10mm cap-head machine (hex drive) (6)
2524	Screws, 2.5x8 countersunk machine (hex drive) (6)
5169	Screws, 2.6x8mm countersunk machine (6) (EZ Start 2 motor)
2674	Screws, 2x6mm roundhead self-tapping (6)
2577	Screws, 3x10mm button-head machine (hex drive) (6)
5282	Screws, 3x12mm button-head machine (6) (Starter attachment screws w/ threadlock)
2578	Screws, 3x12mm button-head machine (hex drive) (6)
2579	Screws, 3x15mm button-head machine (hex drive) (6)
5142	Screws, 3x15mm caphead machine (hex drive) (with split and flat washers) (6)
2553	Screws, 3x15mm countersunk machine (6) (hex drive)
2583	Screws, 3x18 button-head machine (hex drive) (6)
2580	Screws, 3x20mm button-head machine (hex drive) (6)
2575	Screws, 3x6mm button-head machine (hex drive) (6)
2554	Screws, 3x6mm caphead machine (hex drive) (6)
3932	Screws, 3x6mm flat-head machine (hex drive) (6)
2550	Screws, 3x8mm countersunk machine (6) (hex drive)
2535	Screws, 4x10mm countersunk machine (hex drive) (6)
3937	Screws, 4x12mm button-head machine (hex drive) (6)
2547	Screws, 4x18mm countersunk machine (hex drive) (6)
3940	Screws, 4x4 button-head machine, aluminum (blue) (hex drive) (6)
4897	Screws, set (grub) 4mm (6) (w/ threadlock)
3967	Shoulder screws 3x10 (6) (without threadlock)
5149	Spacers, steel (Jato® twin-spoke wheels, front) (4)
5534	Spacers, stub axle carrier (rear)

4147 Wheel nuts, 5mm nylon locking (8)  
5512 Wing mounting hardware, (4x8mmCCS (aluminum)(3)/ 4x7mm flanged NL (3)

### Radio System, Batteries & Chargers

2919 1800mAh 7.2V 6-cell flat NiMH Battery, Power Cell  
3028 **Adapter, Molex to Traxxas® receiver battery pack (for charging) (1)**  
1726 Antenna, tube (1)/ vinyl antenna cap (1)/ wire retainer (1)  
6548 Battery door, TQ 2.4 transmitter (replacement for #6516, 6517 transmitter)  
3039 Battery holder, 4-cell (no on/off switch) (for Jato® and others that use a male Futaba style connector)  
2914 **Battery, Power Cell AA Alkaline (4)**  
3036 **Battery, RX Power Pack (5-cell flat style, GP cells, NiMH, 1200mAh)**  
2977 Charger, D/C, 2 amp (Molex) (5 - 6 cell, 6.0 - 7.2 volt, NiMH)  
6525 **Communication link, telemetry expander**  
2978 **Fuse, D/C charger, 5A (2) (for #2974, 2975, 2977)**  
2010 Gear set (for 2018 servo)  
2053 Gear set (for 2055, 2056 servos)  
6555 **Mount, telemetry expander (fits Slash 4X4, Stampede® 4X4, Rally, Jato®)**  
6536 Mounts, RPM sensor (nitro engines)/ 3x10 CS with split and flat washers (2)  
6533 Receiver, micro, TQi 2.4GHz with telemetry & TSM® (5-channel)  
6552 **Seal kit, expander box (includes o-ring, seals, and silicone grease)**  
6526 **Sensor, auto-detectable, temperature**  
6527 **Sensor, auto-detectable, voltage**  
6522 Sensor, RPM (short)/ 3x4mm BCS (1)/ 3x4mm GS (1)  
6521 Sensor, temperature and voltage (long)  
2052 Servo case (for 2055 servo)  
2075R **Servo, digital high-speed, metal gear (ball bearing), waterproof**  
2070 **Servo, digital high-torque (ball bearing)**  
2075 **Servo, digital high-torque (ball bearing), waterproof**  
2075X **Servo, digital high-torque, metal gear (ball bearing), waterproof**  
2055 Servo, high-torque  
2056 **Servo, high-torque, waterproof (blue case)**  
6553X **Telemetry Expander 2.0 and GPS module 2.0, TQi radio system**  
6550X **Telemetry expander 2.0, TQi radio system (for use only with #6551X GPS module)**  
6551X **Telemetry GPS module 2.0, TQi radio system (for use only with #6550X telemetry expander)**  
6507R **TQi 2.4 GHz High Output radio system, 4-channel with Traxxas® Link Bluetooth® module, TSM® (4-ch transmitter, 5-ch micro receiver)**  
6528 Transmitter, TQi Traxxas® Link enabled, 2.4GHz high output, 2-channel (transmitter only)  
6529 **Transmitter, TQi Traxxas® Link enabled, 2.4GHz high output, 3-channel (transmitter only)**  
6530 **Transmitter, TQi Traxxas® Link enabled, 2.4GHz high output, 4-channel (transmitter only)**  
6511 Traxxas® Link Bluetooth® module  
3038 Wiring harness, on-board radio system (includes on/off switch and charge jack)  
2734 Zip Ties (small)

### Ready-To-Race Model

55077-3 Jato® 3.3: 1/10 Scale 2-Speed Nitro-Powered 2WD Stadium Truck with TQi™ 2.4GHz Radio System, Traxxas Link™ Wireless Module, and Traxxas Stability Management (TSM)®

### Rear Suspension

5555 Carriers, stub axle (rear) (left & right)  
5555X **Carriers, stub axle, (rear) 6061-T6 aluminum (titanium-anodized)**  
5559 Mounts, suspension pin (rear anti-squat blocks) (1.5, 2.25, 3.0 & 3.75 degree) (1 each)  
5525 Rod ends (12)/ hollow balls (12)  
5525R **Rod ends, heavy duty (Jato®/Slayer) (8)**  
5529 Shim set (for adjusting Jato roll center)/ hollow balls (for inner camber links) (4)  
5517 Shock tower, rear  
5534 Spacers, stub axle carrier (rear)  
5553 Stub axles, (rear) (2)  
5533 Suspension arms, rear (left & right)  
5521 Suspension pin set, complete (hardened steel, front & rear), 3x27mm (4) 3x35(2), 3x52mm (4)  
5589X Sway bar kit (front and rear) (includes sway bars and linkage)  
5597 Sway bars (rear) (includes Soft, Medium, Hard)  
5558 Tie bars (front & rear)  
5557 **Tie bars (rear) (3 & 5-degree toe adjustment)**

### Recoil Starter

5277 Shaft, starter (TRX® 2.5 & 2.5R)  
5170 **Starter, recoil (complete with screws) (TRX® 2.5)**

### Shock Oil

5031 Oil, shock (20 wt, 200 cSt, 60cc) (silicone)  
5032 Oil, shock (30 wt, 350 cSt, 60cc) (silicone)  
5033 Oil, shock (40 wt, 500 cSt, 60cc) (silicone)  
5034 Oil, shock (50 wt, 600 cSt, 60cc) (silicone)  
5035 Oil, shock (60 wt, 700 cSt, 60cc) (silicone)  
5036 Oil, shock (70 wt, 900 cSt, 60cc) (silicone)  
5037 Oil, shock (80 wt, 1,000 cSt, 60cc) (silicone)  
5029 Shock oil bottle (60cc) (for mixing shock oil)  
5038X Shock oil set (includes 20 wt, 30 wt, 40 wt, 50 wt, 60 wt, 70 wt, & 80 wt premium shock oils with spinning carousel rack)  
5038 Spinning carousel rack

### Shocks (GTR)

5467A Body, GTR shock (aluminum, blue-anodized) (1)  
5466X Body, GTR shock (hard-anodized, PTFE-coated aluminum) (1)  
5467 Body, GTR shock (molded composite) (2)  
5465 Caps and spring retainers, GTR shock (upper cap (2)/ hollow balls (2)/ bottom cap (2)/ upper retainer (2)/ lower retainer (2))  
5464 **Dust boot, shock (expandable, seals and protects shock shaft)(1 pair)**  
5475 Multi-tool (plastic)  
5158 Nuts, 2.5mm nylon locking (12)  
5562 Rebuild kit, GTR composite shocks (x-rings, bladders, all pistons, piston nuts, shock rod ends) renews 2 shocks  
Rod ends (GTR shocks)  
5469 Shaft, GTR shock (2) (stainless)  
5463 **Shaft, GTR shock TiN-coated (2)**  
5463T **Shocks, GTR (assembled) (2) (without springs)**  
5460A **Shocks, GTR aluminum, blue-anodized bodies with TiN shafts (fully assembled w/o springs) (4)**  
5460R **Shocks, GTR aluminum, red-anodized bodies with TiN shafts (fully assembled w/o springs) (4)**  
5561 Shocks, GTR composite (assembled) (2) (without springs)  
5460X **Shocks, GTR hard-anodized, PTFE-coated aluminum bodies with TiN shafts (fully assembled w/o springs) (4)**  
5461 **Variable damping kit, GTR shocks (includes #1, #2, #3 pistons and stainless steel valves)**

### Slipper Clutch Components

5478 Flat wrench, 8mm (blue anodized aluminum)  
5552A Rebuild kit, slipper clutch (steel disc/ friction pads (3)/ spring (2)/ pin/ 4.0mm NL (1)/ 5.0mm NL (1))  
2554 Screws, 3x6mm caphead machine (hex drive) (6)  
5556 Slipper pressure plate & hub (aluminum alloy)

### Springs

5427 **Spring, shock (GTR) (front 0.7 yellow) (1 pair)**  
5428 **Spring, shock (GTR) (front) (0.9 rate orange) (1 pair)**  
5432 **Spring, shock (GTR) (front) (1.3 rate gold) (1 pair)**  
5429 **Spring, shock (GTR) (rear) (1.0 rate tan) (1 pair)**  
5431 **Spring, shock (GTR) (rear) (1.2 rate silver) (1 pair)**  
5430 Spring, shock (GTR) (std. front) (1.1 rate green) (1 pair)  
5433 Spring, shock (GTR) (std. rear) (1.4 rate pink) (1 pair)  
5433A **Spring, shock (red) (GTR) (1.4 rate double pink stripe)**  
5434A **Spring, shock (red) (GTR) (1.6 rate double blue stripe) (1 pair)**  
5940 **Spring, shock (red) (GTR) (1.8 rate double green stripe) (1 pair)**  
5941 **Spring, shock (red) (GTR) (2.0 rate double black stripe) (1 pair)**  
5942 **Spring, shock (red) (GTR) (2.3 rate double purple stripe) (1 pair)**  
5434 **Spring, shock (white) (GTR) (1.6 rate blue) (1 pair)**

### Spur Gears & Clutch Bells

4118 Clutch bell (18-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x10x4mm ball bearings part 4609)  
4120 Clutch bell (20-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x11x4mm ball bearings part 4611)  
4122 Clutch bell (22-tooth)/5x8x0.5mm fiber washer (2)/ 5mm e-clip (requires 5x11x4mm ball bearings part 4611)  
4124 Clutch bell, (24 tooth) / 5x8x0.5mm fiber washer (2)/ 5mm E-clip (requires #4611-ball bearings, 5x11x4mm (2))  
2554 Screws, 3x6mm caphead machine (hex drive) (6)  
3956 Spur gear, 54-tooth (0.8 metric pitch, compatible with 32-pitch)  
3957 **Spur gear, 56-tooth (0.8 metric pitch, compatible with 32-pitch)**  
3958 **Spur gear, 58-tooth (0.8 metric pitch, compatible with 32-pitch)**

## Steering Components

5123	Bellcrank bushings (plastic) (4x7x2.5mm) (4)
5544	Bellcrank posts (steering)(2)
<b>5542X</b>	<b>Drag link, machined 6061-T6 aluminum (blue-anodized)/ 5x8x2.5 ball bearing (2)</b>
<b>5355X</b>	<b>Hollow ball set, aluminum Revo® (30)/ tall centered hollow ball (2)/ tall offset hollow ball (2)/ bump steer adjustment shims; 3.5mm (2), 1.17mm (2)</b>
5545	Servo horn, steering/ linkage, steering (3x30 threaded rod)/ rod ends (2)/ hollow balls (2)
<b>5545X</b>	<b>Servo horns, steering and throttle (for non-Traxxas® servos (Hitec, JR, KO, Airtronics))</b>
2055	Servo, high-torque
5543	Steering bellcranks/ servo saver/ servo saver spring/ steering support/ 4x7x2.5 PB (4)/ 5x0.8mm NL (1)
5542	Steering drag link/ 3x10mm shoulder screws (without threadlock) (2)
<b>5594</b>	<b>Turnbuckle, aluminum (red-anodized), camber link, 58mm (1)(assembled with rod ends, hollow balls in separate bag)(see part 5539X for complete set of Jato® aluminum turnbuckles)</b>
<b>5595</b>	<b>Turnbuckle, aluminum (red-anodized), front toe link, 61mm (1) (assembled with rod ends and hollow balls)(see part 5539X for complete set of Jato® aluminum turnbuckles)</b>
<b>5539X</b>	<b>Turnbuckles, aluminum (red-anodized), camber links, 58mm (4)/ front toe links, 61mm (2) (assembled with rod ends and hollow balls)/ aluminum 5mm wrench (red-anodized)</b>
5538	Turnbuckles, toe-links, 61mm (front or rear) (2) (assembled with rod ends and hollow balls)

## Suspension Linkage

<b>5529X</b>	<b>Ball studs, aluminum, hard-anodized, PTFE-coated (4) (use for inner camber link mounting)</b>
<b>5355X</b>	<b>Hollow ball set, aluminum Revo® (30)/ tall centered hollow ball (2)/ tall offset hollow ball (2)/ bump steer adjustment shims; 3.5mm (2), 1.17mm (2)</b>
5525	Rod ends (12)/ hollow balls (12)
<b>5525R</b>	<b>Rod ends, heavy duty (Jato®/Slayer) (8)</b>
5521	Suspension pin set, complete (hardened steel, front & rear), 3x27mm (4) 3x35(2), 3x52mm (4)
<b>5594</b>	<b>Turnbuckle, aluminum (red-anodized), camber link, 58mm (1)(assembled with rod ends, hollow balls in separate bag)(see part 5539X for complete set of Jato® aluminum turnbuckles)</b>
<b>5595</b>	<b>Turnbuckle, aluminum (red-anodized), front toe link, 61mm (1) (assembled with rod ends and hollow balls)(see part 5539X for complete set of Jato® aluminum turnbuckles)</b>
<b>5539X</b>	<b>Turnbuckles, aluminum (red-anodized), camber links, 58mm (4)/ front toe links, 61mm (2) (assembled with rod ends and hollow balls)/ aluminum 5mm wrench (red-anodized)</b>
5539	Turnbuckles, camber links, 58mm (assembled with rod ends and hollow balls) (2)
5538	Turnbuckles, toe-links, 61mm (front or rear) (2) (assembled with rod ends and hollow balls)

## Team Traxxas Items

9916	Backpack, RC car carrier, 12" x 12" x 24" (fits TRX-4 & similar)
2514	Decal sheet, racing sponsors
9917	Duffel bag, medium, 30" x 12" x 12" (fits 1/10 Slash®, TRX-4®, & similar)
9950	Official Team Traxxas® racing decal set(flag logo/ 6-color)
9909	Traxxas® racing banner, red & black (3x7 feet)

## Throttle & Brake Linkage

5588	Brake cam
5567	Brake cam lever/ linkage rod/ bellcrank/ 4mm Ball Screw (1)/ 4mm Ball Cup (1)/ 3.0NL (1)/ 3X10 SS (1)
5568	Linkage set, throttle & brake (Jato®) (includes servo horn, rod guides, brake spring, brake adjustment dial, rods (wires), throttle return spring, hardware)
<b>5545X</b>	<b>Servo horns, steering and throttle (for non-Traxxas® servos (Hitec, JR, KO, Airtronics))</b>
4056	Spring, throttle return (2) (Jato®, T-Maxx® 2.5R, 3.3)

## Tires & Wheels

4611	Ball bearings (5x11x4mm) (2)
4607	Ball bearings (5x11x4mm) (8)
1974	Lite-wheels, dished (2) (front)
1972	Lite-wheels, dished (2) (rear)
<b>1747P</b>	<b>Nuts, 4mm flanged nylon locking (aluminum, pink anodized) (4)</b>
<b>3647</b>	<b>Nuts, 4mm flanged nylon locking (steel, serrated) (8)</b>
1747	Nuts, 4mm nylon locking (10)
<b>1747R</b>	<b>Nuts, aluminum, flanged, serrated (4mm) (blue-anodized) (4)</b>
<b>1747G</b>	<b>Nuts, aluminum, flanged, serrated (4mm) (green-anodized) (4)</b>
<b>1747T</b>	<b>Nuts, aluminum, flanged, serrated (4mm) (orange-anodized) (4)</b>
<b>1747A</b>	<b>Nuts, aluminum, flanged, serrated (4mm) (red-anodized) (4)</b>

5149	Spacers, steel (Jato® twin-spoke wheels, front) (4)
2754	Stub axle pins (4)
5577R	Tires & wheels, assembled, glued (All Star chrome wheels, Anaconda® tires, foam inserts) (nitro front) (1 Left, 1 Right)
<b>3777A</b>	<b>Tires &amp; wheels, assembled, glued (All-Star black chrome wheels, Anaconda® tires, foam inserts) (nitro front) (1 left, 1 right)</b>
<b>3776A</b>	<b>Tires &amp; wheels, assembled, glued (All-Star black chrome wheels, Anaconda® tires, foam inserts) (nitro rear/ electric front) (1 left, 1 right)</b>
5576R	Tires & wheels, assembled, glued (All-Star chrome wheels, Anaconda® tires, foam inserts) (nitro rear/ electric front) (1 left, 1 right)
<b>5573</b>	<b>Tires &amp; wheels, assembled, glued (Jato® twin-spoke wheels, Victory tires, foam inserts) (rear) (2)</b>
<b>5569</b>	<b>Tires, Alias 2.8" (soft-compound) (rear) (2)/ foam inserts (2)</b>
5578	Tires, Anaconda® 2.8" (2)/ foam inserts (2)
<b>5563</b>	<b>Tires, ribbed 2.8" (front) (2)/ foam inserts (2)</b>
<b>4790R</b>	<b>Tires, Spiked 2.2 (R) (2) (Soft Compound) w/inserts</b>
<b>5570</b>	<b>Tires, Victory 2.8" (rear) (2)/ foam inserts (2)</b>
<b>4174</b>	<b>TRX® Pro-Star chrome wheels (2) (front) (for 2.2" tires)</b>
<b>4172</b>	<b>TRX® Pro-Star chrome wheels (2) (rear) (for 2.2" tires)</b>
1654	Wheel hubs, hex (2)/ stub axle pins (2)
<b>1654X</b>	<b>Wheel hubs, hex (blue-anodized, lightweight aluminum) (2)/ axle pins(2)</b>
5576	Wheels, All Star 2.8" (chrome) (rear) (2)
<b>5577A</b>	<b>Wheels, All-Star 2.8" (black chrome) (nitro front) (2)</b>
<b>5576A</b>	<b>Wheels, All-Star 2.8" (black chrome) (nitro rear / electric front) (2)</b>

<b>5572</b>	<b>Wheels, Jato® twin-spoke 2.8" (chrome) (rear) (2)</b>
-------------	--

## Transmission Components

5119	Ball bearings, blue rubber sealed (10x15x4mm) (2)
5116	Ball bearings, blue rubber sealed (5x11x4mm) (2)
5592	Clutch guard
5581	Gaskets, differential/transmission
5585	Gear set, 2-speed (2nd speed gear, 29T/ input gear, 17T steel)
5586	Gear, 1st speed 32T/ input gear 14T
5591	Gearbox halves (right & left)
5566	Input shaft (slipper shaft)/ slipper shaft spacer
5593	Primary shaft/ 1st speed hub/one-way bearing/ snap ring/ 5x8x0.5 TV
5583	Rubber plugs, charge jack, 2-speed adjustment (Jato®)
<b>5593X</b>	<b>Single speed conversion kit (eliminates the 2-speed, makes Jato® race legal).</b>

## Traxxas Tools

<b>3433X</b>	<b>Body reamer (aluminum handle)</b>
<b>3433</b>	<b>Body reamer (plastic handle)</b>
<b>3436</b>	<b>Cap, body reamer</b>
<b>3432</b>	<b>Scissors, curved tip</b>
<b>3431</b>	<b>Scissors, straight tip</b>
<b>8712</b>	<b>Speed Bit Essentials Set, hex and nut driver, 7-piece, includes premium handle (medium), travel pouch, hex drivers (straight: 1.5mm, 2.0mm, 2.5mm) and nut drivers (5.0mm, 5.5mm, 7.0mm, and 8.0mm), 1/4" drive</b>
<b>8722</b>	<b>Speed bit handle, premium (rubber overmold)</b>
<b>8710</b>	<b>Speed Bit Master Set, hex and nut driver, 13-piece, includes premium handle (medium), travel pouch, hex drivers (straight: 1.5mm, 2.0mm, 2.5mm, 3.0mm), (ball-end: 2.0mm, 2.5mm, 3.0mm), and nut drivers (4.0mm, 4.5mm, 5.0mm, 5.5mm, 7.0mm, 8.0mm), 1/4" drive</b>
<b>8711</b>	<b>Speed Bit Master Set, hex driver, 7-piece straight and ball end, includes premium handle (medium), travel pouch, hex drivers (straight: 1.5mm, 2.0mm, 2.5mm, 3.0mm) (ball end: 2.0mm, 2.5mm, 3.0mm), 1/4" drive</b>
<b>8719</b>	<b>Speed Bit Master Set, nut driver, 6-piece, includes premium handle (medium), travel pouch, and nut drivers (4.0mm, 4.5mm, 5.0mm, 5.5mm, 7.0mm, 8.0mm), 1/4" drive</b>
<b>8716</b>	<b>Speed Bit Set, hex driver, 2-piece ball-end (2.0mm, 2.5mm), 1/4" drive</b>
<b>8716X</b>	<b>Speed Bit Set, hex driver, 3-piece ball-end (2.0mm, 2.5mm, 3.0mm) 1/4" drive</b>
<b>8715</b>	<b>Speed Bit Set, hex driver, 3-piece straight (1.5mm, 2.0mm, 2.5mm), 1/4" drive</b>
<b>8715X</b>	<b>Speed Bit Set, hex driver, 4-piece straight (1.5mm, 2.0mm, 2.5mm, 3.0mm), 1/4" drive</b>
<b>8714</b>	<b>Speed Bit Set, screwdriver, 3-piece straight (3mm slotted, #1 Phillips, and #2 Phillips bits), 1/4" drive</b>
<b>3415</b>	<b>Tool set with pouch (includes 1.5mm, 2.0mm, 2.5mm, 3.0mm, 3.5mm, 4mm drivers/4mm, 5mm, 5.5mm, 7mm, and 8mm nut drivers/ 2mm, 3mm, and 4mm slotted screwdrivers/ #00 Phillips, #0 Phillips, and #1 Phillips screwdrivers/ 4mm and 8mm wrenches/ driver handle)</b>

### Turnbuckles & Threaded Rods

5477	Flat wrench, 5mm (blue anodized aluminum)
5545	Servo horn, steering/ linkage, steering (3x30 threaded rod)/ rod ends (2)/ hollow balls (2)
5594	Turnbuckle, aluminum (red-anodized), camber link, 58mm (1)(assembled with rod ends, hollow balls in separate bag)(see part 5539X for complete set of Jato® aluminum turnbuckles)
5595	Turnbuckle, aluminum (red-anodized), front toe link, 61mm (1) (assembled with rod ends and hollow balls)(see part 5539X for complete set of Jato® aluminum turnbuckles)
5539X	Turnbuckles, aluminum (red-anodized), camber links, 58mm (4)/ front toe links, 61mm (2) (assembled with rod ends and hollow balls)/ aluminum 5mm wrench (red-anodized)
5539	Turnbuckles, camber links, 58mm (assembled with rod ends and hollow balls) (2)
5538	Turnbuckles, toe-links, 61mm (front or rear) (2) (assembled with rod ends and hollow balls)

### Two-Speed Components

5119	Ball bearings, blue rubber sealed (10x15x4mm) (2)
5116	Ball bearings, blue rubber sealed (5x11x4mm) (2)
5585	Gear set, 2-speed (2nd speed gear, 29T/ input gear, 17T steel)
5586	Gear, 1st speed 32T/ input gear 14T
5590	Primary clutch assembly (2-speed shift hub)
5583	Rubber plugs, charge jack, 2-speed adjustment (Jato®)

If you have questions or need technical assistance, call Traxxas at:

**1-888-TRAXXAS**

(1-888-872-9927) (U.S. residents only)

For orders, calls outside the U.S., and other information, call 972-549-3000, or fax to 972-549-3011 e-mail [support@Traxxas.com](mailto:support@Traxxas.com)

**TRAXXAS.COM**