



NiMH Battery

HT6F1800B Instruction Manual

- Please be sure to read this manual before using the product.
 Keep this manual at hand to be used whenever you need.
- Thank you for purchasing the NiMH battery, HT6F1800B

In order to get high performance from the product and use it safely, please read this instruction manual thoroughly before use.

- Copying a part or all of the contents of this manual without
- prior permission is prohibited.

 The contents of this manual are subject to change without
- prior notice.

 The contents of this manual should be complete. However,
- if you find any errors or omissions, please contact us.

 Futaba is not responsible for the results from the use of this product by the customer.

Applicable Equipment and Battery Charger>

The NiMH battery, HT6F1800B, is designed only for use with Futaba transmitters that require this battery. Don't use it with any other equipment. When you charge, please be sure to connect HT6F1800B to Futaba's transmitter, and to use the exclusive AC charger (an attachment for Futaba transmitters) developed specifically for Futaba equipment.

■ Safety Precautions (Please observe safety precautions fully.)

This instruction manual uses a variety of common symbols and icons to explain the product's proper handling and use, and how to avoid potential hazards to yourself, the people around you, and your property. The meanings of these symbols and their significance are described below. Please understand them clearly before going on to main items.

Meaning of Markings

For safety, please pay special attention to the items indicated by the following marks.

⚠ DANGER Procedures which may have a high risk of death/serious injury to the user if not carried out properly.

⚠WARNING Procedures which may lead to dangerous conditions or cause death or serious injury to the user if not carried out properly, or procedures in which the probability of superficial injury or physical damage is high.

⚠ CAUTION

Procedures in which the possibility of serious injury to the user is small, but there is a danger of injury, or physical damage, if not carried out

O: Prohibited

Mandatory

△ DANGER

If you ignore the following safety precautions, it may cause a fire, ignition, overheating, explosion,the leakage of electrolyte fluid or getting an electric shock.

- Be sure to connect with Futaba's transmitter and to charge with an exclusive AC charger.
- O Do not short-circuit the battery terminals with a metallic object.
- Never expose the battery to water or moisture. Do not charge or use a wet battery.
- Never throw the battery into a fire or place it near a fire.
- O Do not use, charge or store the battery in places where it may be exposed to high temperatures. For example, do not leave it on the dashboard of a car under direct sunlight, and do not place it near heating equipment.
- \bigcirc Never solder the battery or attempt to repair, deform, modify or disassemble it.
- Keep the battery out of reach of children.
- If the electrolyte fluid gets into your eyes, blindness may result from it. Rinse your eyes with clean water without rubbing them, and see a doctor immediately.
- O Do not load the battery into the battery charger with +/- terminals upside down. If the battery does not fit properly into the battery charger, do not force fit into the charger.

AWARNING

- 🛇 To avoid a fire, overheating, explosion or the leakage of electrolyte fluid, do not give the battery excessive shock, throw it, or damage it.
- Olf you notice any abnormalities such as the leakage of electrolyte fluid, discoloration, deformation, overheating, or giving out a bad odor, remove the battery from the equipment or the battery charger immediately and stop using it. Continuing to use the battery under these conditions could result in a fire, overheating or explosion.
- Never put the battery in a microwave oven or high-pressure container. This could cause a fire, the leakage of electrolyte fluid, overheating or explosion.
- If the battery leaks or gives out a bad odor, keep it away from heat sources. Leaked electrolyte fluid may catch fire, causing the battery to smoke, burn or explode
- If the fluid leaked from the battery sticks to your skin or clothes, wash it off immediately with clean water, and see a doctor. That may cause skin problems.
- If charging does not complete in 3 hours, stop the charging to prevent fire, overheating or explosion(The standard charging time is 2 hours and 30 minutes).
- ❶ When you recycle or dispose the battery, use the plastic tape to insulate its terminals. If the battery is short-circuited, it may cause a fire, overheating or explosion. If you want to recycle the battery, please take it to a shop that handles recycled products. If you dispose the battery, please comply with the regulations your city government has set.

↑ CAUTION

- O The NiMH battery, HT6F1800B, is designed only for use with Futaba transmitters that require this battery. Do not use it with any other equipment
- $oldsymbol{\circ}$ The battery gets hot after using the equipment for many hours. To prevent burns, do not touch the battery immediately after use.
- $\boldsymbol{\mathsf{O}}$ Do not store the battery in places where it may be exposed to moisture, excessive dust or high temperatures.
- ${f O}$ Do not place the battery on an unstable surface such as a tilted or unsteady table. If the battery falls off, it may be damaged or cause injury.
- O Do not charge the battery in an environment that is extremely cold or hot. If you use the battery in such an environment, its performance would decrease. Charging the battery in temperatures between 10°C and 30°C (50 and 86 degress F) is recommended.

■Precautions for use

• The battery at the time of purchase:

The battery discharges by itself even if it is not used. When you purchase the battery, please charge it to full capacity before use. Also, whenever the battery has not been used for a long period of time, recharge it before use.

Regarding how to charge it, please refer to the instruction manual of your Futaba

■When you connect the battery:

When you connect the battery to your Futaba transmitter, pay attention to the polarity of the connector. Do not pull wiring when you remove a connector.

● How to care for the battery:

Remove stains from the battery by wiping it with a dry and soft cloth. Do not use a wet cloth, alcohol, thinner, benzene or detergent.

Operating temperatures:

The further the temperature goes down, the more the operating time shortens. When you use the battery at low temperature, it is recommended to have another super-charged battery as a backup.

●Carry and storage:

Do not leave the battery in the battery charger or the equipment when stored. Even when the power switch is off, a small amount of electricity continues to leak out of the battery and may lead to a decrease in battery performance. If you do not use the battery, store it in a cool and dry place with a temperature between 15°C and 25°C (59 and 77 F).

When you carry or store the battery, take steps to avoid short-circuiting of the +/terminals. Do not put any metallic objects including personal ornaments in a bag or drawer with the battery. This could cause a fire, overheating, explosion or the leakage of electrolyte fluid.

● Service life:

Battery performance degrades gradually after repeated charging and discharging. If the operating time of the battery decreases significantly, it may be time to replace it with a new one. Battery capacity usually decreases by half after about 300 charge/discharge cycles, depending on the operating conditions.

Recycling of unneeded batteries:



The RBRC. SEAL on the nickel battery contained in Futaba products indicates that Futaba Corporation of America is voluntarily participating in an industry-wide program to collect and recycle these batteries at the end of their useful lives, when taken out of service within the United States. The RBRC. program provides a convenient alternative to placing used nickel batteries into the trash or municipal waste system, which is illegal in some areas.

(for USA)



You may contact your local recycling center for information on where to return the spent battery. Please call 1-800-8BATTERY for information on NiMH battery recycling in your area. Futaba Corporation of America's involvement in this program is part of its commitment to protecting our environment and conserving natural resources.

*RBRC is a trademark of the Rechargeable Battery Recycling Corporation.

[Specifications of HT6F1800B]

Type: Rechargeable NiMH battery

Nominal output voltage: DC 7.4V

Nominal capacity: 1800mAh Charging/discharging count: Approximately 300 cycles,

depending on the operating conditions.

Ambient temperatures:

 $0^{\circ}\text{C} \sim 45^{\circ}\text{C}$ (32F~ 113F) for recharging,

 $-20^{\circ}\text{C} \sim 60^{\circ}\text{C}$ (-4F~ 140F) for operation,

 $0^{\circ}\text{C} \sim 25^{\circ}\text{C}$ (32F~ 77F) for storage (3 months or more.)

Dimensions: Approximately 34.5mm (W) x 131.5mm (L) x 17.5mm (H)

Weight: Approximately 171g (6.03oz)

- This product cannot be repaired because it is designed not to be disassembled for
- If you have questions about this product, please contact our radio control service center.

*The specifications are subject to change without