Futaba

M23N23101

S.BUS System Channel Changer

SBC-I



INSTRUCTION MANUAL

Before using your new SBC-1, please read this manual thoroughly and use the system properly and safely. After reading this manual, store it in a safe place.

Thank you for purchasing an SBC-1, S.BUS¹¹ channel changer.

This product is a tool for setting the channel to **S.BUS** servo and **S.BUS** decoder of Futaba **S.BUS** system.

"S.BUS: Serial communication system for Futaba R/C system


Applicable items:

S.BUS servo, S.BUS decoder

Usage Precautions

∆CAUTION


Connect the servo and battery connector in the correct polarity. Connecting the power + and - polarities in reverse by mistake may cause smoke, fire, and damage.



Do not disassemble or modify this product. Futaba Corp. will not be responsible for any disassembly or modification other than those specified by us.

Futaba Corp. will not be responsible for damage caused by combination with other than Futaba Genuine parts.

Name of Each Part and Accessories



∆CAUTION

To prevent the entry of foreign matter, do not remove the connector dust cover of the vacant connectors. Channel setting cannot be performed at the connector under the cover.


S.BUS servo connection port Battery connection port

<Accessories>

Mini screwdriver

 Use the miniature screwdriver to operate the channel select switch and the set switch.

Instruction manual (this manual)



Channel Setting

- 1 Connect an S.BUS servo to the S.BUS servo connection port (S.BUS).
- 2 Connect a battery to the battery connection port (BATT.)

| ı | LED | Status | |
|---|---|--|--|
| | Blinks slowly (approximately 1 time/second) | When the CHANNEL SELECT switch No. and the channel set at the S.BUS servo are different. | |
| | Lights steadily | When the CHANNEL SELECT switch No. and the channel set at the S.BUS servo are the same. | |

- 3 Set the CHANNEL SELECT switch No. to the channel you want to set at the S.BUS servo.
- 4 Hold down the set switch (**SW**). (Approximately 1 second)
- *During channel setting, the LED blinks rapidly (approximately 5 times/second) and then lights steadily.
- *When the **LED** lights steadily, channel setting is complete.
- 5 Remove the battery.
- 6 Remove the S.BUS servo.

Refer to the instruction manual of each device for a description of the channel setting method of the **S.BUS** compatible devices (**S.BUS** decoder, etc.) other than a servo.

Precautions

•Do not connect the power source with the SW pressed down. If the power source is connected when the SW is pressed, the LED will light and

operation will become impossible. In this case, reconnect the power source before reuse.

•Channel setting cannot be performed simultaneously at multiple S.BUS servos. Always connect only one S.BUS servo to the SBC-1. If multiple S.BUS servos are connected using a Y-harness, etc., channel setting will not be performed at any S.BUS servo.

Errors

When channel setting cannot be performed correctly because of improper connection of the **S.BUS** servo or the **S.BUS** decoder, etc., the **SBC-1** is in error mode and the **LED** continuously blinks rapidly (about 5 times/second).

| LED | Status |
|--|---|
| Blinks rapidly (about 5 times/ second) | When channel setting cannot be performed correctly. |

In this case, check the following:

Check items

- •Is a battery connected to the battery connection port?
- Is an S.BUS servo or S.BUS decoder connected to the S.BUS servo connection port?
- Are the battery and S.BUS servo connectors firmly inserted fully?
- •Are the battery and **S.BUS** servo cables damaged, broken, etc?
- · Is the battery charged?

Meaning of Special Markings

= Prohibited

Pay special attention to safety where indicated by the following marks:

| △DANGER | Procedures which may lead to dangerous conditions and cause death/serious injury if not carried out properly. |
|----------|--|
| ∆WARNING | Procedures which may lead to a dangerous condition or cause death or serious injury to the user if not carried out properly, or procedures where the probability of superficial injury or physical damage is high. |
| △CAUTION | Procedures where the possibility of serious injury to the user is small, but there is a danger of injury, or physical damage, if not carried out properly. |

[SBC-1 Ratings]

- Dimensions: 1.54x1.02x0.39in. (39x26x10mm)
- Weight: 0.28oz. (7.8g)
- Power requirement: Ni-Cd, Ni-MH 4 cells to 5 cells equivalent battery (Futaba)
- Operating temperature range:
 -10 to +45°

©Copyright 2010. No part of this manual may be reproduced in any form without prior permission. The contents of this manual are subject to change without prior notice. While this manual has been carefully written, there may be inadvertent errors or omissions. Please contact our service center if you feel that any corrections or clarifications should be made.

= Mandatory

FUTABA CORPORATION oak kandakajicho 8F 3-4 Kandakajicho, Chiyoda-ku, Tokyo 101-0045, Japan TEL: +81-3-4316-4820, FAX: +81-3-4316-4823